

CONDENSATE DRAIN PANS



Secondary Condensate Drain Pan Installation Instructions

Installation of Drain Pan Adapter Fitting:

- A. Place rubber gasket over the male threads of the PVC Adapter.
- B. Insert fitting into drain line outlet on the pan from the outside of the pan.
- C. Secure the fitting in place using the nut provided. Make certain that the gasket is seated against the outside drain pan wall.

Installation of Drain Pan Adapter Fitting:

- A. Install drain pan on fully supported surface.
- B. Make certain that the pan is a minimum of 3 inches larger than the coil or unit dimension in width and length.

Installation of A/C Equipment in the pan:

- A. Run your condensate drain line outside in accordance with applicable codes.
- B. Position blocks between ribs of the pan in at least 6 or 8 locations.
- C. Place unit into installed drain pan.